



#### **BEVPURE® PV FILTER CARTRIDGES**

Hydrophilic PVDF Mebrane for sterile liquid filtration

# **BEVPURE® PV FILTER CARTRIDGES**

### HYDROPHILIC PVDF MEMBRANE FILTERS DESIGNED FOR HIGH THROUGHPUT, STERILIZED FILTRATION

BevPure® PV Filter Cartridges are made of unique hydrophilic polyvinylidene fluoride (PVDF) membrane characterized by high throughput and low binding. These filters are suitable for the sterilized filtration of a wide range of beverage applications.

FEATURE	BENEFIT		
Hydrophilic PVDF	Low extractable and protein binding		
membrane	Broad chemical compatibility and temperature resistance		
	Excellent durability proven by testing forward/reverse pulse up to 100x		
	Ideal for the removal of particles and beverage-spoiling microorganisms		
Bacterial Retention	Retention of 10 <sup>7</sup> cfu/cm <sup>2</sup> Brevundimonas diminuta (ATCC® 19146) according to ASTM F838.		
Quality Assurance	Manufactured in a facility which adheres to ISO 9001Practices. 100% Integrity tested and lot traceable.		
Indirect Food Additive	All component materials meet the FDA Indirect Food Additive requirements cited in 21 CFR 177–182.		
SPECIFICATIONS			
Filter media	Hydrophilic PVDF membrane		
Supports/core/cage/end caps	Polypropylene		
O-rings	Silicone, EPDM, FKM, FEP/PFA encapsulated FKM		
O-ring internal support ring	PBT		
Effective filtration area	0.66m² (7.1 ft²)/ Ø69-10 inch		
Cartridge diameter	69 mm (2.7 in.)		
Max. Operating temperature	80°C		
Max. Operating pressure	0.69 MPa (6.9 bar, 100 psi) at 25°C; 0.24 MPa (2.4 bar, 35 psi) at 80°C		
Max. Differential pressure	Forward: 0.69 MPa (6.9 bar, 100 psi) at 25°C ; 0.24 MPa (2.4 bar, 35 psi) at 80°C Reverse: 0.30 MPa (3.0 bar, 43.5 psi) at 25°C ; 0.10 MPa (1.0 bar, 15 psi) at 80°C		
Bubble point	0.45 µm + 0.22 µm: ≥0.32 MPa (3.2 bar, 46 psi) (water)		
Steam sterilization (saturated steam)	up to 100 cycles for 30 minutes at 135°C at Max. Differential Pressure of 0.3 bar (4.3 psi), forward & reverse		
Chemical sanitization	up to 50 cycles for 30 minutes at 40°C with mix solution of sodium hypochlorite (NaClO, 100 ppm) and peroxyacetic acid (100 ppm)		
Hot water sterilization	up to 50 cycles for 30 min. at 85°C and Max. Differential Pressure of 2 bar (29 psi)		
Autoclave	up to 400 cycles for 30 min. at 130°C		



#### **Microbiological Control**

The primary purpose of a membrane filter cartridge in beverage processing is to effectively control spoilage microorganisms.

	TYPICAL LOG REDUCTION VALUE (LRV)			
	Brevundimonas diminuta	Lactobaccilus brevis	Saccharomyces cerevisiae	
0.22 μm + 0.22 μm	> 7/cm <sup>2</sup>	N/A	N/A	
0.45 μm + 0.22 μm	> 7/cm <sup>2</sup>	N/A	N/A	

Log Reduction Values are calculated using the following formula: LRV=log<sub>10</sub> (total number of organisms entering the filter)

#### **FLOW RATES**



#### **ORDERING INFORMATION**

EXAMPLE: BPPVII4522HTC10S-F = 0.45 µm + 0.22 µm, 222/Flat, 10" filter with silicone seals



## BannerIndustries

BANNER INDUSTRIES IS THE EXCLUSIVE DISTRIBUTOR FOR COBETTER PRODUCTS IN THE USA Visit www.bannerindustries.com and select the Contact Us link to find the location nearest you. The Banner Industries of N.E., Inc. Terms and Conditions of Sale apply and are fully and expressly incorporated herein by reference and constitute a part of any contract for the purchase of the products described herein.